

EXTENDED MULTIFUNCTION SMITH MACHINE






TABLE OF CONTENT

Page 2	Table of content
Page 3-4	Safety Instructions
Page 5-6	Technical data overview
Page 7-10	Parts list
Page 11-36	Assembling steps
Page 37	Cleaning/Maintenance/Disposal
Page 38	Warranty
Page 39-40	Training information
Page 41	
Page 42-43	Notes



IMPORTANT INFORMATION AND SAFETY INSTRUCTIONS

General information

Please ensure that all persons using the device have read and understood the assembly and operating instructions. The assembly and operating instructions must be regarded as part of the product and kept in a safe place so that they can be referred to at any time if necessary. Ensure that the safety and maintenanceinstructions are followed exactly. Any use that deviates from these instructions may result in damage tohealth, accidents or damage to the device, for which the manufacturer and distributor cannot accept any liability.

Personal safety

Before starting to use the device, you should consult your family doctor to determine whether the training is suitable for you from a health point of view. This applies especially to people who have a hereditary predisposition to high blood pressure or heart disease, smoke, have high cholesterol levels, are overweight and/or have not exercised regularly in the last year. If you are on medication that affects your heart rate, medical advice is absolutely essential. Please also note that excessive exercise can seriously jeopardize your health. If you experience any signs of weakness, nausea, dizziness, pain, shortness of breath or other abnormal symptoms during training, please stop training immediately and consult a doctor in case of emergency.

As a general rule, sports equipment is not a toy. Unless otherwise described, the equipment may only be used by one person at a time for training. It may therefore only be used as intended and by appropriately informed and instructed persons. Persons such as children, invalids, physically and mentally impaired persons should only use the device in the presence of another person who can provide assistance and guidance. Suitable measures should be taken to prevent unsupervised children from using the device. It must be ensured that the user and other persons never move or stand with any parts of their body in the area of moving parts.



IMPORTANT INFORMATION AND SAFETY INSTRUCTIONS

Training clothes and shoes suitable for fitness training with the device must be worn. The clothing must be such that it cannot get caught in the device during training due to its shape (e.g. length). The training shoes should be chosen to match the training equipment, basically give the foot a firm grip and have a non-slip sole.

Assembly


Check that all parts and tools listed in the parts list are present. Please keep in mind that some parts may be pre-assembled. Keep children and animals away from the assembly area during assembly. Tools, packaging materials (e.g. foil) or small parts may pose a risk of injury or suffocation. Also make sure that you have enough space to move around during assembly. Beforeusing the device for the first time and at regular intervals, check the tightness of all screws, nuts and other connections to ensure the safe operating condition of the device.

Location

Set up the device in a flat, stable and dry place. Uneven surfaces can be compensated by adjustable parts of the device, if available. To protect sensitive surfaces against pressure marks and dirt, we recommend placing a floor protection mat underneath. Please also remove all objects within the required training radius before starting training. Use outdoors or in rooms with increased humidity is not permitted.





TECHNICAL DATA OVERVIEW





TECHNICAL DATA OVERVIEW










No.	Description	Note	Qty.
1	base frame left		1
2	upright frame left		1
3	base frame right		1
4	front connecting frame		1
5	upright frame right		1
6	back connecting frame		1
7	connecting plate	140x50xT3.0	6
8	hexagon bolt	M10x20	14
9	hexagon bolt	M10x90	17
10	hexagon bolt	M10x75	4
11	lock nut	M10	54
12	washer	Ф10	137
13	washer	Ф8	12
14	lock nut	M8	2
15	hanging ring		1
16	upright tube		2
17	back support tube		1
18	upper connecting tube long		1
19	upper connecting tube short		2
20	base frame short		1
21	connecting plate	t6.0x70x130	1
22	double pulley bracket big		1
23	hexagon bolt	M10x25	12
24	hexagon bolt	M10x80	2
25	hexagon bolt	M10x70	6
26	hexagon bolt	M10x55	2
27	spring washer	Ф10	8
28	back guide hollow rod		2
29	back sliding sleeve		1
30	barbell plate holder		2
31	headless hexagon socket bolt	M8x10	4
32	rubber cushion	Ф60хФ26х40	2
33	link part		1
34	extension arm left		1
35	extension arm right		1
36	support frame		1
37	double pulley bracket small		2
38	hexagon bolt	M10x65	2

PARTS LIST

39	connecting plate	t3.0x50x110	2
40	lock nut	M16	2
41	big washer	Ф30хФ16.5х2.0	2
42	hexagon bolt	M8x20	8
43	extension arm cushion	300x200x40	2
44	guide rod		2
45	guide rod lock sleeve		2
46	safety hook left		1
47	safety hook right		1
48	rubber cushion	Ф60хФ58хФ26х25	4
49	barbell clamp collar		2
50	sliding sleeve left		1
51	sliding sleeve right		1
52	barbell inside bar	Ф25х1952	1
53	barbell bar	423 X1332	1
54	barbell bar plug	Ф50.5хФ42.5х36.6L	2
55	barbell bar stop collar	Φ60xΦ48.5x27L	2
56	pipe	Ф48x298x2.5T	2
57	pipe	Φ48λ298λ2.51 Φ50x310xT0.5	2
58	spring washer	Ф30х310х10.3	2
	washer	Φ12 Φ12	2
59			2
60	hexagon socket button head bolt	M12x40	
61	cable	L=2630mm	1
62	double pulley plate	405 440 5 25 4	1
63	pulley	Ф95хФ10.5х25.4	22
64	pulley catch plate	20x96xT3	4
65	"-" shaped pulley frame		1
66	hexagon bolt	M10x50	4
67	hexagon bolt	M10x45	20
68	cable	L=3600mm	1
69	9 section chain + snap hook		4
70	short bar		1
71	big pulley	Ф126	1
72	footplate		1
73	cable	L=10930mm	1
74	powder metallurgy sleeve	Ф15.5х25	2
75	back cushion		1
76	core trainer		1
77	barbell bar cup		1
78	hexagon bolt	M8x65	2
79	barbell bar storage		6
80	barbell bar cup		1
81	safety catch long		2
82	dip bar		1
83	J hook		2
84	ship bar		1
85	handle belt		2
86	cable	L=3100mm	1
87	cross pulley frame		1
-	· · · · · · · · · · · · · · · · · · ·		_




PARTS LIST






PARTS LIST




ASSEMBLING STEPS



No.	Description	Note	Qty.
1	base frame left		1
2	upright frame left		1
3	base frame right		1
4	front connecting frame		1
5	upright frame right		1
6	back connecting frame		1
7	connecting plate	140x50xT3.0	4
8	hexagon bolt	M10x20	8
9	hexagon bolt	M10x90	8
10	hexagon bolt	M10x75	4
11	lock nut	M10	12
12	washer	Ф10	32
13	washer	Ф8	2
14	lock nut	M8	2
15	hanging ring		1
16	upright tube		2

ASSEMBLING STEPS

1



1.Fix upright frame left-2 fastening on base frame left-1 using M10x20 hexagon bolt-8, Φ10 washer-12


2.Fix upright frame right-5 fastening on base frame right-3 using M10x20 hexagon bolt-8, Φ10 washer-12

3. Fix upright tube-16 fastening on upright frame left-2 and upright frame right-5 using M10x75 hexagon bolt-10, Φ 10 washer-12, M10 lock nut-11

4.Fix hanging ring-15 fastening on front connecting frame-4 using Φ8 washer-13, M8 lock nut-14


5.Fix front connecting frame-4 and back connecting frame-6 fastening on upright frame left-2 and upright frame right-5 using M10x90 hexagon bolt-9, Φ10 washer-12, M10 lock nut-11, connecting plate-7






No.	Description	Note	Qty.
7	connecting plate	140x50xT3.0	2
9	hexagon bolt	M10x90	6
11	lock nut	M10	13
12	washer	Ф10	30
17	back support tube		1
18	upper connecting tube long		1
19	upper connecting tube short		2
20	base frame short		1
21	connecting plate	t6.0x70x130	1
22	double pulley bracket big		1
23	hexagon bolt	M10x25	4
24	hexagon bolt	M10x80	2
25	hexagon bolt	M10x70	3
26	hexagon bolt	M10x55	2
27	spring washer	Ф10	4

ASSEMBLING STEPS




- 1. Fix double pulley bracket big-22 fastening on base frame short-20 using M10x55 hexagon bolt-26, Φ 10 washer-12, M10 lock nut-11
- 2. Fix base frame short-20 fastening on back connecting frame-6 using M10x25 hexagon bolt-23, Φ 10 washer-12, Φ 10 spring washer-27
- 3.Fix upper connecting tube long-18 fastening on front connecting frame-4 using M10x25 hexagon bolt-23, Φ 10 washer-12, Φ 10 spring washer-27
- 4.Fix back support tube-17 fastening on upper connecting tube long-18 and base frame short-20 using M10x80 hexagon bolt-24, M10x70 hexagon bolt-25, Φ10 washer-12, M10 lock nut-11, connecting plate-21 5.Fix upper connecting tube short-19 fastening on upright frame left-2 and upright frame right-5 using M10x90 hexagon bolt-9, Φ10 washer-12, M10 lock nut-11, connecting plate-7






No.	Description	Note	Qty.
12	washer	Ф10	3
23	hexagon bolt	M10x25	2
25	hexagon bolt	M10x70	1
28	back guide hollow rod		2
29	back sliding sleeve		1
30	barbell plate holder		2
31	headless hexagon socket bolt	M8x10	2
32	rubber cushion	Ф60хФ26х40	2

ASSEMBLING STEPS




- 1.Fix barbell plate holder-30 fastening on back sliding sleeve-29 using M8x10 hexagon bolt-31
- 2. Sliding back guide hollow rod-28 into back sliding sleeve-29 and rubber cushion-32
- 3. Fix back guide hollow rod fastening on base frame short-20 using M10x70 hexagon bolt-25, M10x25 hexagon bolt-23, Φ 10 washer-12

ASSEMBLING STEPS




No.	Description	Note	Qty.
11	lock nut	M10	4
12	washer	Ф10	12
13	washer	Φ8	8
23	hexagon bolt	M10x25	4
25	hexagon bolt	M10x70	2
27	spring washer	Ф10	4
33	link part		1
34	extension arm left		1
35	extension arm right		1
36	support frame		1
37	double pulley bracket small		2
38	hexagon bolt	M10x65	2
39	connecting plate	t3.0x50x110	1
40	lock nut	M16	2
41	big washer	Ф30хФ16.5х2.0	2
42	hexagon bolt	M8x20	8
43	extension arm cushion	300x200x40	2

ASSEMBLING STEPS




- 1.Fix support frame-36 and double pulley bracket small-37 fastening on back support tube-17 using M10x70 hexagon bolt-25, Φ 10 washer-12, M10 lock nut-11, connecting plate-39
- 2.Fix extension arm left-34 and extension arm right-35 fastening on link part-33 using big washer-41, M16 lock nut-40
- 3. Fix extension arm cushion-43 fastening on extension arm left-34 and extension arm right-35 using M8x20 hexagon bolt-42, Φ 8 washer-13
- 4. Fix link part-33 fastening on back support tube-17 using M10x25 hexagon bolt-23, Φ 10 washer-12, Φ 10 spring washer-27

ASSEMBLING STEPS




No.	Description	Note	Qty.
31	headless hexagon socket bolt	M8x10	2
44	guide rod		2
45	guide rod lock sleeve		2
46	safety hook left		1
47	safety hook right		1
48	rubber cushion	Ф60хФ58хФ26х25	4
49	barbell clamp collar		2
50	sliding sleeve left		1
51	sliding sleeve right		1
52	barbell inside bar	Ф25х1952	1
53	barbell bar		1
54	barbell bar plug	Ф50.5хФ42.5х36.6L	2
55	barbell bar stop collar	Ф60хФ48.5х27L	2
56	pipe	Φ48x298x2.5T	2
57	pipe	Φ50x310xT0.5	2
58	spring washer	Ф12	2
59	washer	Ф12	2
60	hexagon socket button head bolt	M12x40	2

ASSEMBLING STEPS




- 1.Sliding guide rod-44 into rubber cushion-48, safety hook left-46, safety hook right-47, sliding sleeve left-50, sliding sleeve right-51
- 2.Fix guide rod fastening on upright frame left and upright frame right using M8x10 headless hexagon socket bolt-31
- 3.Put barbell inside bar-52 through sliding sleeve left-50, barbell bar-53, sliding sleeve right-51
- 4.Fix barbell bar stop collar-55,pipe-56, pipe-57, barbell bar plug-54 in turn fastening on barbell bar using M12x40 hexagon bolt-60, Φ 12 washer-59 and Φ 12 spring washer-58






No.	Description	Note	Qty.
11	lock nut	M10	4
12	washer	Ф10	8
61	cable	L=2630mm	1
62	double pulley plate		1
63	pulley	Ф95хФ10.5х25.4	4
64	pulley catch plate	20x96xT3	2
65	"-" shaped pulley frame		1
66	hexagon bolt	M10x50	2
67	hexagon bolt	M10x45	2




- 1. Fix pulley-63 fastening on upper connecting tube long-18 using M10x45 hexagon bolt-57, M10x50 hexagon bolt-66, Φ 10 washer-12, M10 lock nut-11, pulley catch plate-64
- 2.Fix pulley-63 fastening on "-" shaped pulley frame-65 using M10x45 hexagon bolt-67, Φ10 washer-12, M10 lock nut-11
- 3. Fix double pulley plate-62 on cable-61
- 4. According to the picture in turn through the cable





No.	Description	Note	Qty.
11	lock nut	M10	3
12	washer	Ф10	6
63	pulley	Ф95хФ10.5х25.4	3
67	hexagon bolt	M10x45	3
86	cable	L=3100mm	1
87	cross pulley frame		1




- 1. Fix pulley-63 fastening on cross pulley frame-87 using M10x45 hexagon bolt-67, Φ 10 washer-12, M10 lock nut-11
- 2. According to the picture in turn through the cable

ASSEMBLING STEPS


8 67 67 11 (2 63 69 67)

No.	Description	Note	Qty.
11	lock nut	M10	3
12	washer	Ф10	6
63	pulley	Ф95хФ10.5х25.4	3
67	hexagon bolt	M10x45	3
86	cable	L=3100mm	1
87	cross pulley frame		1




- 1. Fix pulley-63 fastening on cross pulley frame-87 using M10x45 hexagon bolt-67, Φ 10 washer-12, M10 lock nut-11
- 2. According to the picture in turn through the cable

ASSEMBLING STEPS




No.	Description	Note	Qty.
9	hexagon bolt	M10x90	1
11	lock nut	M10	4
12	washer	Ф10	10
23	hexagon bolt	M10x25	2
63	pulley	Ф95хФ10.5х25.4	3
67	hexagon bolt	M10x45	3
68	cable	L=3600mm	1
69	9 section chain + snap hook		2
70	short bar		1
71	big pulley	Ф126	1
72	footplate		1

ASSEMBLING STEPS




- 1.Fix pulley-63 and big pulley-71 fastening on pulley frame using M10x45 hexagon bolt-67, M10x90 hexagon bolt-9, Φ 10 washer-12, M10 lock nut-11
- 2. According to the picture in turn through the cable
- 3.Fix footplate-72 fastening on base frame using M10x25 hexagon bolt-23, Φ10 washer-12
- 4. Hang 9 section chain + snap hook-69 and short bar-70 on cable-68






No.	Description	Note	Qty.
11	lock nut	M10	12
12	washer	Ф10	26
63	pulley	Ф95хФ10.5х25.4	12
64	pulley catch plate	20x96xT3	2
66	hexagon bolt	M10x50	2
67	hexagon bolt	M10x45	12
73	cable	L=10930mm	1
74	powder metallurgy sleeve	Ф15.5x25	2






- 1. Fix pulley-63 fastening on pulley frame using M10x45 hexagon bolt-67, Φ10 washer-12, M10 lock nut-11
- 2. According to the picture in turn through the cable

ASSEMBLING STEPS




No.	Description	Note	Qty.
9	hexagon bolt	M10x90	2
11	lock nut	M10	2
12	washer	Ф10	4
13	washer	Ф8	2
39	connecting plate	t3.0x50x110	1
75	back cushion		1
76	core trainer		1
77	barbell bar cup		1
78	hexagon bolt	M8x65	2

ASSEMBLING STEPS



- 1.Fix back cushion-75 fastening on back support tube-17 using M8x65 hexagon bolt-78, Φ8 washer-13
- 2. Fix barbell bar cup-77 fastening on base frame left using M10x90 hexagon bolt-9, Φ 10 washer-12, M10 lock nut-11, connecting plate-39
- 3. Fix core trainer on base frame right


ASSEMBLING STEPS



No.	Description	Note	Qty.
8	hexagon bolt	M10x20	6
12	washer	Ф10	6
79	barbell bar storage		6



12




1.Fix barbell bar storage-79 fastening on upright frame left and upright frame right using M10x20 hexagon bolt-8, Φ10 washer-12

ASSEMBLING STEPS

88)

No.	Description	Note	Qty.
69	9 section chain + snap hook		2
80	barbell bar cup		1
81	safety catch long		2
82	dip bar		1
83	J hook		2
84	ship bar		1
85	handle belt		2





- 1. Hang handle belt-85 and 9 section chain + snap hook-69 on cable
- 2.Put ship bar-84 into barbell bar cup
- 3. Hang dip bar left-80, dip bar right-82, safety catch long-81 and J hook on upright tube



CLEANING/ MAINTENANCE/DISPOSAL

Cleaning

Please use only a slightly damp cloth for cleaning. Attention! Never use gasoline, thinner or other aggressive cleaning products to clean the surface, as this may cause damage. The device is only suitable for private home and for indoor use. Keep the device clean and moisture away from the device. Damage caused by body sweat or other liquids is not covered by the warranty under any circumstances.

Maintenance

We recommend checking the screws and moving parts at regular intervals. The device may only be used for training if it is working properly. For possible repairs or needed spare parts, please contact our customer service. WARNING: The device may only be used after it has been successfully repaired.

Disposal

In the interest of the environment, do not dispose of the packaging materials, empty batteries and parts of the device with the household waste, but throw them into the designated collection containers or hand them in at suitable collection points. Observe the currently valid regulations.

WARRANTY



The warranty is 24 months, applies to new goods at first purchase and begins with the invoice or delivery date. During the warranty period, any defects will be repaired free of charge. If you find a defect, you are obliged to report it immediately to the seller. It is at the discretion of the seller to fulfill the warranty by sending spare parts or replacement. In case of shipment of spare parts, the seller has the right to replace without loss of warranty. Repair at the place of installation is excluded. Devices for home use are not suitable for commercial or industrial use. Violation in the use will result in warranty reduction or loss. Warranty coverage applies only to defects in materials or workmanship. Wear parts or damage caused by misuse or improper handling, use of force and interventions made without prior consultation with our service department will void the warranty. If possible, please keep the original packaging for the duration of the warranty period in order to adequately protect the goods in the event of a return and do not send any goods carriage forward to our address. A claim under warranty does not result in an extension of the warranty period. Claims for compensation for damage that may occur outside the device (unless liability is mandatory regulated by law) are excluded.

Manufacturer:

Gorilla Sports GmbH Nordring 80 64521 Groß-Gerau

Here you can find an overview of our international partners: **www.gorillasports.eu.**

TRAINING INFORMATION

Training preparations

Before you start training, not only must the training equipment be in perfect condition, but you or your body should also be ready for training. Therefore, if you have not done any strength/endurance training for a long time, you should always consult your family doctor before starting your training and carry out a fitness check-up. Please also discuss your training goals with your doctor; he or she can certainly give you valuable tips and information. In particular, this applies to people over 35 years of age, people who are overweight and/or have problems with the cardiovascular system.

Workout planning

The be-all and end-all for effective, goal-oriented, but also motivating training is planning your workouts. Therefore, plan your fitness training into your normal daily routine as a fixed component. Unplanned training can quickly become a disruptive factor, or be postponed indefinitely for another task. Plan your workout for the long term, for months at a time, and not just from day to day or week to week. Training planning also includes providing sufficient motivation during the workout. Music is ideal for this. Also provide training rewards. Set realistic goals, such as losing 1 kg in four weeks, increasing your training weight by 10 kg in six weeks, or similar. When your goals are achieved, reward yourself!

Training frequency

Experts recommend doing endurance/strength training 3 to 4 days a week. Certainly, the more often you train, the faster you will reach your training goal. However, when planning your workout, make sure to take sufficient breaks from training to give your body enough time to recover and regenerate. You should-take at least one day off after each training session.

TRAINING INFORMATION

Hydration

Sufficient fluid intake is essential before and during training. During a training session of 60 minutes, it is quite possible to lose up to 0.5 liters of fluid. To compensate for this fluid loss, apple spritzer in amixing ratio of one-third apple juice and two-thirds mineral water is ideal, as it contains and replacesall the electrolytes and minerals that the body loses through sweat. 30 minutes before the start of your training session you should drink about 330 ml. Ensure a balanced fluid intake during your workout.

Warm-Up

Complete a warm-up before each training session. Warm up your body by 5 - 7 minutes before the actual training session at low load with skipping rope, cross trainer or similar. This is the best way to prepare yourself for the upcoming workout.

Cool-Down

Never stop training immediately after finishing your actual training program. Let your training, similar to the warm-up phase still 5 - 7 minutes at low load on an exercise bike, cross trainer, etc. loosely run out. Afterwards, you should always stretch your muscles well.

WARM-UP/STRETCHING

Thighs



Support yourself with your right hand against a wall or your exercise equipment. Lift the left foot backward and hold it with the left hand. The knee points straight down. Now pull your thigh back until you feel a slight stretchin the muscle. Hold this position for 15 - 20 seconds. Slowly release your foot and slowly put the leg down again. Now repeat this exercise with the right leg.

Legs and lower back



Sit on the floor with your legs stretched out.

Try to grasp the tops of your feet with both hands, stretching your arms and bending your upper body slightly forward.

Hold this position for 15 to 20 seconds. Release the tops of your feet and slowly and steadily straighten your upper body.


Triceps and shoulder



Reach behind your head to your right shoulder with your left hand and pull on your left elbow with your right hand until you feel a slight tug. Hold this position for 15-20 seconds.

Now repeat this exercise with the right hand.

Upper body



Bring your extended left arm past your right arm at shoulder level and pull on your left upper arm with your right hand until you feel a slight tug. Hold this position for 15-20 seconds.

Now repeat this exercise with your right hand.











NORDRING 80, 64521 GROB-GERAU WWW.GORILLASPORTS.EU